

DMX Channel	DMX value	Detail function
1, Total function control	0~8	Close light
	8~135	Dimmer
	135~240	Strobe
	240~255	On-Off
2, RED LED Dimming	0~255	Dimming from dark to brightness
3, Green LED Dimming	0~255	Dimming from dark to brightness
4, Blue LED Dimming	0~255	Dimming from dark to brightness
5, White LED Dimming	0~255	Dimming from dark to brightness
6, Auto	<=8	No operation
	<32	Mode1
	<64	Mode2
	<80	Mode3
	<96	Mode4
	<112	Mode5
	<128	Mode6
	<144	Mode7
	<160	Mode8
	<176	Mode9
	<192	Mode10
	<208	Mode11
	<224	Mode12
	<240	Sound Mode1
	<250	Sound Mode2
	<256	Sound Mode3

LED Colorful Beam Pinspot



User Manual

Please read the user manual careful before use

Thank you so much to choose this product; it is adopting the most advanced lamps, which is called LED lamps. It conquers a lot of disadvantages such as power wasting, short using life, high temperature, etc. It has advantages of power saving, long life (it can reach 60,000.00 hours in general circs), high brightness, fresh colors...It is the best stage illuminating and various effect decorative products.

Security:

1. Make sure the user voltage cannot higher or lower than the regulate value of the user manual.
2. Please take more attention while installing the fixtures. Avoid touching exposed AC cord, or will cause deadly accident.
3. When installing the fixtures, make sure the fixtures are not exposed in extremely hot, humid or dusty environment. Make sure the distance between the fixture and the lighted object is not less than 0.5 meter. Make sure there is no combustible or explosive object.
4. Please operate the light fixture after becoming very familiar with the functions. In most cases, the light fixture will be broken by incorrect operation. It won't allow laypeople to operate this light.

Menu Function:

MENU	Display	Function		
1	A001	DMX512 (press "enter" changing to channel mode option)		
2	RUNx	Running mode choose X (soud is sound control)		
3	color	Color manual dimming, press "enter" changing different color mode		
4	leon/loff	Nixie tube free, Bright or close, has running state, display lamp display		
RUNX	<=8	No operation	RUN0	clear

	<32	Mode1	RUN1	4 color jump
	<64	Mode2	RUN2	Red background 3 color jump
	<80	Mode3	RUN3	Green background 3 color jum
	<96	Mode4	RUN4	Blue background 3 color jum
	<112	Mode5	RUN5	White background 3 color jum
	<128	Mode6	RUN6	All white slow gradient
	<144	Mode7	RUN7	All white fast gradient
	<160	Mode8	RUN8	RED GREEN gradient
	<176	Mode9	RUN9	RED BLUE gradient
	<192	Mode10	RUN10	BLUE GREEN gradient
	<208	Mode11	RUN11	Colorful gradient
	<224	Mode12	RUN12	Colorful jump
	<250	Sound Mode2	SOU2	Sound control conservation
	<256	Sound Mode3	SOU3	Sound control strobe
color	rxxx	0~255	Dimming from dark to brightness	
	gxxx	0~255	Dimming from dark to brightness	
	bxxx	0~255	Dimming from dark to brightness	
	yxxx	0~255	Dimming from dark to brightness	