

LED Moving Head Light 10W/30W/60W

Addr	A001-A512	512 Adress Set
CHnd	11CH	11CH Set
	9CH	9CH Set
SLnd	MAST	Master Mode
	SL 1	dmx Mode
	SL 2	Slave Mode
SHnd	SH 0	Effect0 (Suggest)
	SH 1	Effect1
	SH 2	Effect2
	SH 3	Effect3
Soud	on	Sound Mode On
	oFF	Sound Mode Off
SEnS	0-99	Adjust Sound Sensitivity
bLAnd	bLAc	DMX 0
	Auto	DMX Auto
	Soun	DMX Sound
	HoLd	HOLD DMX
LEd	OFF	LED OFF ater 5s
	ON	LED On
dISP	no	Display reverse
	YES	Display Positive
rPAN	no	X Step Motor foreward
	YES	X Step Motor reversal
rTiL	no	Y Step Motor foreward
	YES	Y Step Motor reversal
REST	YES	RESET

9CH

ch	FUNCTION	Instroduction
1	X	0-255
2	Y	0-255
3	Color	
	0-139	Choose Color
	140-255	Automatic color-changing Fast to slow
4	GOBO	
	0-63	Fixed GOBO
	64-127	GOBO Shake
	128-255	Automatic GOBO-changing Fast to slow
5	Strobe	0-255
6	DIMMER	0-255
7	X	0-255
8	Auto Mode	0-255
9	Reset	250-255 (5s)